

## LiteDimmer Spectrum Firmware

**New Firmware Version: 2.0**

**Replacing Version: <=1.10**

Release Date: 07/15/2020

Changed	Details
Local Operation.	Turn to adjust, tap to advance to the next parameter, and Intensity is always active.
Parameter Presets.	Offers 6 pre-set values each for CCT, Accent Color, and Saturation - 216 possible combinations.
Parameter Nudge.	Combines the use of rotary encoders along with screen-side buttons to adjust parameters.
Audition.	Turns the light output on and off while making parameter adjustments.
Tint Function.	Color temperature does not drastically change when adding green or magenta regardless of intensity.
Menu Settings.	Settings are always available when the main switch is centered.
Screen Fidelity and Options.	The screen can now time-out after 30 seconds, rotate orientation for when ballast is hanging, and an optimized screen refresh rate.
Intelligent Encoder.	The rotation speed of the encoder adjusts to slowly or quickly advancing the value.
Quick Access to Users Guide.	Scanning the on-screen QR code provides access to the users guide.
Operational Settings for Local and DMX.	Settings for local-operation are now stored independently from DMX settings.
Ballast Status.	Feedback screens show status of power, sensors, and reset count.

### NOTES:

Firmware for LiteMat Spectrum may be updated with the use of a dedicated Updater Cable. For more information, see <http://www.litegear.com/firmware> Be sure to read warnings and notices in the LiteMat Spectrum user's guide.